

KRANBILER						KG/M	KG/M	KG/M	KG/M	KG/M	KG/M	KG/M	KG/M	MAX	KR/TIME	HENGER
BIL	sjåfør	REGNR	NYTTEL	PLAN		1	5	8	10	12	15	16	21			
MB Actros	TOMMY	NF 64579	<b>27T/M</b>	11875	650		5300	2500	1860	1480	1240			16,7m	890	
Volvo FH	DARKO	ZZ25562	<b>50T/M</b>	11415	650		9270	4780	3700	3000	2200					
MB Actros	Tommy		<b>37T/M</b>		650		7500	3750	2940	2360		1660	550	26 m/jibb		
MB Actros		FT 27972	<b>13T/M</b>	10335	600		2845	1490						8m	890	
Volvo FM	Ove	ZZ25603	<b>32T/M</b>	12685	650		6070	3010	2310	1850						

TM= TONN METER, V= VINSJ, J= JIBB. TABELL VISER LØFTEKAPASITET FRA SENTER BIL I KG. VEKTER ER CA BEREGN MARGIN  
HENGER + 25%